

GARMIN inReach Mini2 Your GARMIN inReach Mini2 needs to be turned on.



The mini needs a clear view of the sky for best signal. The most favoured position is on top of your camelback or backpack (or just inside the top pocket of your pack), or the least favourable position is in your rear pocket of your pack.

Only if the unit is mounted correctly can we receive consistent data from you.

The unit is not to be allowed to swing loosely. **Protect the unit it may save your life!**

A brief description of the Preset Messages for communication are as below. To send a Preset Message – 1. From the **Home Screen** (this is the one with the time and/or distance on it) push the OK button select **Presets** – 2. Select a **Preset Message** – 3. **Select Send.**

- **Level 1 - Preset 1 = I am OK**
- **Level 2 - Preset 3 = I want to pull out of the event**
- **Level 3 - Preset 2 – HELP = Need pick up**
- **Level 4 – SOS (SOS Emergency) Lift the cap on right had side to access SOS Button, and press and hold the SOS button. Wait for the SOS countdown. Only send an SOS in an emergency = I require immediate Medical support at this location.**

If you receive a message on the device arrow down (left hand side) then press OK (right hand side) to read the message.

DO NOT SWITCH THE UNIT OFF UNLESS INSTRUCTED